

# Inmarsat LaunchPad version 5.01 for Intel Mac OS X

Briefing note  
27<sup>th</sup> September 2011

Inmarsat LaunchPad version 5.01 for Mac OSX operating system has been released and is available for download now. Please go to [www.inmarsat.com/support](http://www.inmarsat.com/support), click on **BGAN** or **FleetBroadband**, then click on **Inmarsat LaunchPad**.

## In this Release

- SMS Caching
- Auto Update
- Support for User Profile Maker

## Recommendations for installation

Inmarsat advises that all customers using Intel MAC OSX install BGAN LaunchPad version 5.01 to take advantage of the features of this custom-designed interface to your Inmarsat terminal.

## Land Portable Terminals Supported

- Thrane & Thrane EXPLORER 100
- Thrane & Thrane EXPLORER 110
- Thrane & Thrane EXPLORER 300
- Thrane & Thrane EXPLORER 500
- Thrane & Thrane EXPLORER 700
- Thrane & Thrane EXPLORER 700 WOW
- HUGHES 9201
- HUGHES 9202
- Harris FALCON @III RF-7800B-DU
- Wideye SABRE 1
- Wideye SAFARI

## Land Mobile Terminals Supported

- Thrane & Thrane Explorer 325
- Thrane & Thrane EXPLORER 527
- Thrane & Thrane EXPLORER 727
- HUGHES 9250
- HUGHES 9350
- HUGHES 9350 C11
- HUGHES 9450 C11
- Harris FALCON @III RF-7800B-VU
- Glocom GX-10
- Glocom GX-11

## FleetBroadband Terminals Supported

- Thrane & Thrane Sailor 150
- Thrane & Thrane Sailor 250
- Thrane & Thrane Sailor 500
- Furuno Felcom 250
- Furuno Felcom 500
- JRC JUE -250
- JRC JUE-500
- AddValue Skipper 150
- Satlink FB250

## Installing LaunchPad version 5.01

- a. Download the installer from [www.inmarsat.com/support](http://www.inmarsat.com/support), click on **BGAN** or **FleetBroadband**, then click on **Inmarsat LaunchPad**. Follow the on-screen instructions to download the installer to your desktop.
- b. Double-click on the Inmarsat LaunchPad installer.
- c. Follow the on-screen instructions. The Inmarsat LaunchPad icon is installed on your desktop. Double-click on the icon to open Inmarsat LaunchPad.

## Also In this Release

- Improvements to UT Profiles
- Minor bug fixes

## Further documentation

The Inmarsat LaunchPad User Manual for either BGAN or FleetBroadband is available at [www.inmarsat.com/support](http://www.inmarsat.com/support). Click on **BGAN** or **FleetBroadband** and click **Inmarsat LaunchPad**.

## [inmarsat.com/bgan](http://inmarsat.com/bgan)

Whilst the above information has been prepared by Inmarsat in good faith, and all reasonable efforts have been made to ensure its accuracy, Inmarsat makes no warranty or representation as to the accuracy, completeness or fitness for purpose or use of the information. Inmarsat shall not be liable for any loss or damage of any kind, including indirect or consequential loss, arising from use of the information and all warranties and conditions, whether express or implied by statute, common law or otherwise, are hereby excluded to the extent permitted by English law. INMARSAT is a trademark of the International Mobile Satellite Organisation. Inmarsat LOGO is a trademark of Inmarsat (IP) Company Limited. Both trademarks are licensed to Inmarsat Global Limited. © Inmarsat Global Limited 2008. All rights reserved.